
FIRE PROTECTIVE CLOSURE

FIREMISER[™] INSULATED ROLLING FIRE DOOR Model ERD20

MEASURE THE WIDTH AND HEIGHT OF THE OPENING

DOOR SIZE AND AREA




Opening Width in Feet


COMPONENT DIMENSIONS

Reference the zone number to view component dimensions for motorized doors.

Dimensions in Inches	1	14	16	6	7.5
	2	15	17	6	7.5
	3	16	18	6	7.5
	4	17	19	6	7.5
	5	18	20	6	7.5
	6	19	21	6	7.5
	7	20	22	6	7.5
	Zone	А	В	С	D



INSULATED SLAT




The dimensions featured on this sheet are provided as a guide. Please visit our website at www.cornelliron.com/drawings to generate drawings on demand with exact dimensions.



GUIDE CONSTRUCTION OPTIONS


FACE OF WALL Z

Typically used with masonry wall construction, guides are mounted to the interior or exterior side of the wall.




BETWEEN JAMBS

Used when side clearance is minimal, guides are mounted to the inside of the jamb.



FACE OF WALL E

Typically used with steel jambs, guides are mounted to the interior or exterior side of the wall.



R Value of 5.3

U Value of .189

Calculated using the ASHRAE Handbook of Fundamentals

The dimensions featured on this sheet are provided as a guide. Please visit our website at www.cornelliron.com/drawings to generate drawings on demand with exact dimensions.

CUSTOM-DESIGNED SOLUTIONS

Our experienced Architectural Design Support Team can customize our products to fit your specific application. Call 800.233.8366 ext. 4551 • ads@cornelliron.com

